

Installation / Operation Manual

Upflow Water Filter

For Model Numbers :

U10

U15

U20

U25

CSI Inc.

220 Ohio Street
Ashland, OH 44805
(419) 281-5767

INSTALLATION INSTRUCTIONS

1. **Unpacking** : Check product label located on outside of tank carton against cartons received. The large carton contains the filter tank. Underbed gravel and filling material are packaged separately.
2. **Location** : For complete customer satisfaction, all water in the home should be filtered with the exception of the outside faucets. Select a location near the water service inlet. Be certain that all sides of the filter are easily accessible for service and maintenance. On a private water system, locate filter after the pressure tank.
3. **Mineral** : The filling material is shipped separately from the tank. The tank must be loaded with mineral after the tank has been placed at the desired location. Remove the manifold by unscrewing from center hole. Leave distributor tube in tank while filling. Plug top of distributor tube to prevent mineral from entering tube while filling. Place funnel in hole. Pour several gallons of water in the tank. On all filters, first pour in the "D" gravel and then the filling material. The required quantity of each type of filter material is shown under specifications. When filled, the tank should be approximately two-thirds full. Fill tank with water by using a garden hose or several buckets of fresh water. This will permit the filtering material to become soaked while preparing the installation. Remove funnel and plug from distributor tube. Replace the manifold, being careful to position the distributor tube into the distributor tube pilot.
4. **Water Supply Connections** : Inlet and outlet connections are 1" pipe size. Turn off the main water supply and connect pipes, valves and fittings.

Note : If using neutralizer media for pH correction, filter material will need to be added to the media tank approximately every six (6) months to one (1) year. If using carbon material, media will need to be **replaced** every one - two years, depending on the application.